verilux®
The Healthy Lighting Company™



Original | Deluxe

VD01

Natural Spectrum® Desk Lamp

IMPORTANT SAFETY INSTRUCTIONS

SAVE THESE INSTRUCTIONS

Thank you for purchasing the Original Natural Spectrum® Deluxe Desk Lamp. Please read the following safety information before using. To reduce the risk of fire, electrical shock, or injury to persons:

- Do NOT dismantle.
- Do NOT alter power cord.
- Turn off/unplug and allow to cool before replacing bulb or cleaning.
- For indoor use only.
- The lamp is an electrical device. DO NOT USE NEAR WATER

GENERAL PRECAUTIONS

- Before plugging in the lamp, check to make sure the voltage corresponds with the main voltage of your location (120 volts).
- Do not use the lamp outside or in wet locations such as bathrooms. It is intended for indoor, dry use only.
- Not for use with light dimmers, timers, motion detectors or extension cords.
- This product may cause interference with radios, cordless telephones, or devices that use a wireless remote control, such as televisions. If interference occurs, move the product away from the device, plug the product or device into a different outlet, or move the lamp out of the line of sight of the remote control receiver.
- The light bulb may become loose during transit. To reinstall the light bulb, see the bulb installation instructions on page 6.
- Do NOT use lubricating agent in assembly; please see troubleshooting section if you are having difficulty assembling your lamp.
- Unplug from electrical outlet for extended periods of non-use or during lightning storms to ensure protection of the electronics.

GETTING STARTED

Main Parts & Controls

A. Lamp Head
B. Gooseneck
C. Lamp Base
D. Power Cord
E. Polarized Plug
F. Parabolic Grid Diffuser
G. Bulb
H. High/Off/Low Switch





SET-UP INSTRUCTIONS

1. Attaching the Parabolic Grid Diffuser

- Remove grid diffuser from protective plastic bag
- Insert plastic pegs at bottom of grid diffuser into openings near bulb socket
- Snap tab into place

2. Plug lamp into outlet and turn on; if bulb does not illuminate instantly, please refer to the troubleshooting section of this manual.



BULB REPLACEMENT INSTRUCTIONS

Removal

1. Unplug lamp from power source.

2. To access to the bulb, remove grid diffuser by depressing the tab and lifting it out. (See page 5)

3. Firmly hold bulb base (B) and pull bulb (C) from the socket (A) in an outward motion.



Installation

1. Unplug lamp from power source.

2. Firmly hold base (B) and push bulb (C) into the socket (A).

3. Be sure bulb is firmly seated in the socket (see below) and snapped into the metal bulb clip (D).

4. Replace grid diffuser.



YES



Correctly seated bulb

Fig. 10

NO



Incorrectly seated bulb

CARE & CLEANING

Your lamp is made from high quality materials that will last for many years with minimum care. You may want to periodically clean the lamp, using a mild non-abrasive cleaner and soft cloth. When cleaning, make sure you have turned off and unplugged the unit, and allowed sufficient time for the unit to cool. All liquid should be properly wiped away and dried prior to restoring power.

DO NOT USE SOLVENTS OR CLEANERS CONTAINING ABRASIVES, OR AMMONIA BASED CLEANERS

Note: *All moisture should be properly wiped away and dried prior to restoring power.*

TROUBLESHOOTING

Before Requesting Service on Your Verilux® Lamp, Please Read the Following:

- Make sure all power connectors, cords, and plugs are inserted fully and securely.
- Be sure the bulb is securely seated into the socket. (See page 8)
- Make sure there is power to the wall outlet or try another outlet.

PROBLEM	CHECK	SOLUTION
Light won't come on	Has the plug come loose?	Insert plug securely into wall outlet.
	Is the bulb old?	Check the bulb for blackening/darkening at the ends (an indicator of bulb life) and replace bulb.
	Is the bulb connected securely to the socket?	Be sure the bulb is securely seated into the socket, repeat the bulb installation process.
Blackening/darkening at ends of bulb	Is the bulb new?	Sometimes when a new bulb is turned on for the first time the tube will darken, but this will fade after a few minutes.
	Is the bulb old?	With older bulbs darkening of the tube indicates end of bulb life. (This doesn't affect operation except to reduce the amount of light available since the phosphor in that area has become inactive). Bulb replacement is recommended.
Light flickers	Has the plug come loose?	Insert plug securely into wall outlet.
	Is the bulb connected securely to the socket?	Be sure the bulb is securely seated into the socket, repeat the bulb installation process.
	Is the lamp connected to a dimmer switch?	Connect lamp plug only to wall outlet without a dimmer switch.